EXPANDABLE
movable spaces

USER MANUAL

Electric sliding door remote control

Sensor setup

APPLICABLE TO

All Expandable types with electric sliding doors




Release: 10-2026

1. The remote control and sensor

This manual explains how to use the remote control for the automatic sliding doors of the trailer. It covers how to calibrate the door sensor.

In each step, the button to press is highlighted in yellow on the remote. The image next to it shows the light the sensor should give after you press it.



Buttons used

1	**Magic wand**	Settings mode
2	**0**	Calibrate the sensor
3	**Unlock**	Start a procedure
4	**Closed lock**	Reset when a procedure fails

Sensor light


Off


Blinking red


Blinking green

2. Setup

Calibrate the door sensor.

	PRESS	BUTTON → WHAT HAPPENS	SENSOR
1		**Unlock button** Sensor starts blinking red	
2		**Magic wand button** Sensor starts blinking faster	
3		**0 button** Sensor blinks red and green	

The doors will open and close to calibrate the sensor.
Do this on the outside and on the inside of the trailer.

Keep a good distance from the sensor and make sure there are no objects within a 2m range.

3. Troubleshooting



If at first you don't succeed, press the closed lock button, then try again. Don't press any other buttons.

EXPANDABLE
movable spaces

Any questions?
Contact us

Expandable B.V.
Meerheide 25
5521 DZ Eersel
The Netherlands

+31 (0)85 890 21 88
info@expandable.nl

www.expandable-trailers.com

Release: 10-2026